



# Technical Data

## Nexus Grid Rockers

### Brief product description:

The Nexus Grid range is ideal for domestic, commercial and industrial applications, and allows you to build your own module configurations with a variety of combinations and finishes.

### Features:

- Replacement rockers available in all finishes
- Plastic – printed, metal – embossed
- Supplied in packs of 10
- Easy to fit on standard Grid switch modules

### Product Images




### Printed / Embossed Rocker options include:

Hob, Oven, Fan, Washing Machine, Tumble Dryer, Fridge, Freezer, Fridge Freezer, Boiler, Microwave, Cooker Hood, Water Heater, Waste Disposal, Air Con, Dish Washer, Bell Symbol, Wine Cooler, Warming Drawer

### Unprinted Rocker Options include:

White, Black Nickel, Polished Chrome, Brushed Steel, Part M (Graphite), Red, Antique Brass

### Line Diagrams





# Nexus Grid Rockers

## Packaging Information

Cat No.	Description	Packaging Type			Pack Quantity			Barcode		
		Product	Inner Box	Outer Box	Each	Inner Box	Outer Box	Individual	Inner Box	Outer Box
<b>White Moulded</b>										
RRHBW	"HOB"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765204781	5050765205535	5050765206280
RROVW	"OVEN"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765204798	5050765205542	5050765206297
RRFNW	"FAN"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765204804	5050765205559	5050765206303
RRMWW	"WASHING MC"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765204811	5050765205566	5050765206310
RRTDW	"TUMBLE DRYER"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765204828	5050765205573	5050765206327
RRFDW	"FRIDGE"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765204835	5050765205580	5050765206334
RRFZW	"FREEZER"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765204842	5050765205597	5050765206341
RRFFW	"FRIDGE FREEZER"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765204859	5050765205603	5050765206358
RRBLW	"BOILER"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765204866	5050765205610	5050765206365
RRMWW	"MICROWAVE"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765204873	5050765205627	5050765206372
RRCHW	"COOKER HOOD"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765204880	5050765205634	5050765206389
RRWHW	"WATER HEATER"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765204897	5050765205641	5050765206396
RRWCW	"WINE COOLER"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765227063	5050765227070	5050765227087
RRWDW	"WARMING DRAWER"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765230940	5050765231015	5050765231084
RRWDISW	"WASTE DISPOSAL"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765204903	5050765205658	5050765206402
RRACW	"AIR CON"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765204910	5050765205665	5050765206419
RRDWW	"DISH WASHER"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765204927	5050765205672	5050765206426
RRBELLW	BELL SYMBOL	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765204934	5050765205689	5050765206433
RRHTW	"HEATER"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765204958	5050765205702	5050765206457
RRUPW	WHITE (UNPRINTED)	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765204941	5050765205696	5050765206440
<b>Evolve White</b>										
RRACPCDW	"AIR CON"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765233439	5050765233798	5050765234153
RRBELLPCDW	BELL SYMBOL	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765233453	5050765233811	5050765234177
RRBLPCDW	"BOILER"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765233385	5050765233743	5050765234108
RRCHPCDW	"COOKER HOOD"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765233408	5050765233767	5050765234122
RRDWPCDW	"DISH WASHER"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765233446	5050765233804	5050765234160
RRFNPCDW	"FAN"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765233323	5050765233682	5050765234047
RRFZPCDW	"FREEZER"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765233361	5050765233729	5050765234085
RRFDPCDW	"FRIDGE"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765233354	5050765233712	5050765234078
RRFFPCDW	"FRIDGE FREEZER"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765233378	5050765233736	5050765234092
RRHTPCDW	"HEATER"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765233460	5050765233828	5050765234184
RRHBPCDW	"HOB"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765233309	5050765233668	5050765234023
RRMWPCDW	"MICROWAVE"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765233392	5050765233750	5050765234115
RROVPCDW	"OVEN"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765233316	5050765233675	5050765234030
RRTDPCDW	"TUMBLE DRYER"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765233347	5050765233705	5050765234061
RRWCPCDW	"WINE COOLER"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765237215	5050765237222	5050765237239
RRWMPCDW	"WASHING MC"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765233330	5050765233699	5050765234054
RRWDISPCDW	"WASTE DISPOSAL"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765233422	5050765233781	5050765234146
RRWHPCDW	"WATER HEATER"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765233415	5050765233774	5050765234139
RRWDPCDW	"WARMING DRAWER"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765237246	5050765237253	5050765237260
RRUPPCDW	WHITE (UNPRINTED)	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765233477	5050765233835	5050765234191
<b>Evolve Black</b>										
RRACPCDB	"AIR CON"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765233613	5050765233972	5050765234337
RRBELLPCDB	BELL SYMBOL	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765233637	5050765233996	5050765234351
RRBLPCDB	"BOILER"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765233569	5050765233927	5050765234283
RRCHPCDB	"COOKER HOOD"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765233583	5050765233941	5050765234306
RRDWPCDB	"DISH WASHER"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765233620	5050765233989	5050765234344
RRFNPCDB	"FAN"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765233507	5050765233866	5050765234221
RRFZPCDB	"FREEZER"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765233545	5050765233903	5050765234269
RRFDPCDB	"FRIDGE"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765233538	5050765233897	5050765234252
RRFFPCDB	"FRIDGE FREEZER"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765233552	5050765233910	5050765234276
RRHTPCDB	"HEATER"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765233644	5050765234009	5050765234368
RRHBPCDB	"HOB"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765233484	5050765233842	5050765234207
RRMWPCDB	"MICROWAVE"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765233576	5050765233934	5050765234290
RROVPCDB	"OVEN"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765233491	5050765233859	5050765234214
RRTDPCDB	"TUMBLE DRYER"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765233521	5050765233880	5050765234245
RRWCPCDB	"WINE COOLER"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765237154	5050765237161	5050765237178
RRWMPcdb	"WASHING MC"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765233514	5050765233873	5050765234238
RRWDISPCDB	"WASTE DISPOSAL"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765233606	5050765233965	5050765234320
RRWHPCDB	"WATER HEATER"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765233590	5050765233958	5050765234313
RRWDPCDB	"WARMING DRAWER"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765237185	5050765237192	5050765237208
RRUPPCDB	WHITE (UNPRINTED)	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765233651	5050765234016	5050765234375



# Nexus Grid Rockers

## Packaging Information

Cat No.	Description	Packaging Type			Pack Quantity			Barcode		
		Product	Inner Box	Outer Box	Each	Inner Box	Outer Box	Individual	Inner Box	Outer Box
<b>Polished Chrome</b>										
RRHBPC	"HOB"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765204989	5050765205733	5050765206488
RROVPC	"OVEN"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765204996	5050765205740	5050765206495
RRFNPC	"FAN"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765205009	5050765205757	5050765206501
RRWMPC	"WASHING MC"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765205016	5050765205764	5050765206518
RRTDPC	"TUMBLE DRYER"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765205023	5050765205771	5050765206525
RRFDPC	"FRIDGE"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765205030	5050765205788	5050765206532
RRFZPC	"FREEZER"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765205047	5050765205795	5050765206549
RRFFPC	"FRIDGE FREEZER"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765205054	5050765205801	5050765206556
RRBLPC	"BOILER"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765205061	5050765205818	5050765206563
RRMWPC	"MICROWAVE"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765205078	5050765205825	5050765206570
RRCHPC	"COOKER HOOD"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765205085	5050765205832	5050765206587
RRWHPC	"WATER HEATER"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765205092	5050765205849	5050765206594
RRWCPC	"WINE COOLER"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765230957	5050765231022	5050765231091
RRWDPC	"WARMING DRAWER"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765230964	5050765231039	5050765231107
RRWDISPC	"WASTE DISPOSAL"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765205108	5050765205856	5050765206600
RRACPC	"AIR CON"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765205115	5050765205863	5050765206617
RRDWPC	"DISH WASHER"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765205122	5050765205870	5050765206624
RRBELLPC	BELL SYMBOL	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765205139	5050765205887	5050765206631
RRHTPC	"HEATER"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765205146	5050765205894	5050765206648
RRUPPC	PLAIN	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765205153	5050765205900	5050765206655
<b>Brushed Steel</b>										
RRHBBS	"HOB"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765205160	5050765205917	5050765206662
RROVBS	"OVEN"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765205177	5050765205924	5050765206679
RRFNBS	"FAN"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765205184	5050765205931	5050765206686
RRWMBS	"WASHING MC"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765205191	5050765205948	5050765206693
RRTDBS	"TUMBLE DRYER"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765205207	5050765205955	5050765206709
RRFDBS	"FRIDGE"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765205214	5050765205962	5050765206716
RRFZBS	"FREEZER"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765205221	5050765205979	5050765206723
RRFFBS	"FRIDGE FREEZER"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765205238	5050765205986	5050765206730
RRBLBS	"BOILER"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765205245	5050765205993	5050765206747
RRMWBS	"MICROWAVE"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765205252	5050765206006	5050765206754
RRCHBS	"COOKER HOOD"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765205269	5050765206013	5050765206761
RRWHBS	"WATER HEATER"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765205276	5050765206020	5050765206778
RRWCBS	"WINE COOLER"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765230971	5050765231046	5050765231114
RRWDBS	"WARMING DRAWER"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765230988	5050765231053	5050765231121
RRWDISBS	"WASTE DISPOSAL"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765205283	5050765206037	5050765206785
RRACBS	"AIR CON"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765205290	5050765206044	5050765206792
RRDWBS	"DISH WASHER"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765205306	5050765206051	5050765206808
RRBELLBS	BELL SYMBOL	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765205313	5050765206068	5050765206815
RRHTBS	"HEATER"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765205320	5050765206075	5050765206822
RRUPBS	PLAIN	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765205337	5050765206082	5050765206839
<b>Black Nickel</b>										
RRHBNN	"HOB"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765205344	5050765206099	5050765206846
RROVBN	"OVEN"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765205351	5050765206105	5050765206853
RRFNBN	"FAN"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765205368	5050765206112	5050765206860
RRWMBN	"WASHING MC"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765205375	5050765206129	5050765206877
RRTDBN	"TUMBLE DRYER"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765205382	5050765206136	5050765206884
RRFDBN	"FRIDGE"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765205399	5050765206143	5050765206891
RRFZBN	"FREEZER"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765205405	5050765206150	5050765206907
RRFFBN	"FRIDGE FREEZER"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765205412	5050765206167	5050765206914
RRBLBN	"BOILER"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765205429	5050765206174	5050765206921
RRMWBN	"MICROWAVE"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765205436	5050765206181	5050765206938
RRCHBN	"COOKER HOOD"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765205443	5050765206198	5050765206945
RRWHBN	"WATER HEATER"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765205450	5050765206204	5050765206952
RRWCBN	"WINE COOLER"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765230995	5050765231060	5050765231138
RRWDBN	"WARMING DRAWER"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765231008	5050765231077	5050765231145
RRWDISBN	"WASTE DISPOSAL"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765205467	5050765206211	5050765206969
RRACBN	"AIR CON"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765205474	5050765206228	5050765206976
RRDWBN	"DISH WASHER"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765205481	5050765206235	5050765206983
RRBELLBN	BELL SYMBOL	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765205498	5050765206242	5050765206990
RRHTBN	"HEATER"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765205504	5050765206259	5050765207003
RRUPBN	PLAIN	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765205511	5050765206266	5050765207010



# Nexus Grid Rockers

## Packaging Information

Cat No.	Description	Packaging Type			Pack Quantity			Barcode		
		Product	Inner Box	Outer Box	Each	Inner Box	Outer Box	Individual	Inner Box	Outer Box
<b>Red</b>										
RRUPRD	PLAIN	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765204965	5050765205719	5050765206464
<b>Graphite</b>										
RRUPG	PLAIN	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765204972	5050765205726	5050765206471
<b>Antique Brass</b>										
RRUPAB	PLAIN	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765205528	5050765206273	5050765207027

## Weights & Dimensions

Cat No.	Description	Dimensions (H x W x D) cm			Weight (kg)			CBM (m <sup>3</sup> )
		Product	Inner Box	Outer Box	Each	Inner Box	Outer Box	Outer Box
RR**W	White Rocker (All variants)	1 X 8.8 X 6	7 X 9.7 X 11.8	13.1 X 20.3 X 35.8	0.03	0.33	3.47	0.00952
RR**PC	Polished Chrome Rocker (All variants)	1 X 8.8 X 6	7 X 9.7 X 11.8	13.1 X 20.3 X 35.8	0.046	0.49	5.07	0.00952
RR**BS	Brushed Steel Rocker (All variants)	1 X 8.8 X 6	7 X 9.7 X 11.8	13.1 X 20.3 X 35.8	0.048	0.51	5.27	0.00952
RR**BN	Black Nickel Rocker (All variants)	1 X 8.8 X 6	7 X 9.7 X 11.8	13.1 X 20.3 X 35.8	0.048	0.51	5.27	0.00952
RRUPRD	Red Rocker (Plain)	1 X 8.8 X 6	7 X 9.7 X 11.8	13.1 X 20.3 X 35.8	0.043	0.46	4.77	0.00952
RRUPG	Graphite Rocker (Plain)	1 X 8.8 X 6	7 X 9.7 X 11.8	13.1 X 20.3 X 35.8	0.043	0.46	4.77	0.00952
RRUPAB	Antique Brass Rocker (Plain)	1 X 8.8 X 6	7 X 9.7 X 11.8	13.1 X 20.3 X 35.8	0.043	0.46	4.77	0.00952
RR**PCD*	Evolve Rockers (all variants)	1 X 8.8 X 6	6.2 x 7.7 x 14.7	16.5 x 16 x 32	0.03	0.33	3.48	0.00845